





SINGLE CONTROL



This schematic diagram shows the layout of Air control lines and connections to the Hoist Hydraulic single control lever and valve system.

DUAL CONTROL



This schematic diagram shows the layout of Air control lines and electrical wiring connections to the Hoist Hydraulic dual control lever and valve system.